THANK YOU TO CHOOSE A LAINER SUSPENSION PRODUCT.

EVERY PART THAT YOU BOUGHT HAS TO BE MOUNTED BY A PROFESSIONAL SUSPENSION TECHNICIAN.

THESE ARE THE INSTRUCTIONS TO MOUNT THE 4CS KIT CODE WP4CS-COMP-ADJ

THIS KIT WILL IMPROVE THE PERFORMANCE OF YOUR WP 4CS ADDING 2 COMPRESSION ADJUSTER ON THE BOTTOM, YOU WILL HAVE 2 COMPRESSION ADJUSTER ON THE BOTTOM AND 2 REBOUND ADJUSTER ON THE TOP.

TO REACH THE BEST QUALITY FROM YOUR JOB YOU MUST REMOVE THE 2 NEEDLES INSIDE THE RED AND GREY ALUMINUM CONE WHICH HOLD THE REBOUND PISTON.

BASE VALVE KIT MOUNTING INSTRUCTIONS

- 1. DISMOUNT BOTH COMPLETE CARTRIDGES FROM THE FORKS AND CLEAN ALL THE COMPONENTS.
- 2. DISMOUNT THE COMPLETE COMPRESSION PISTON AND SHIMS FROM THE STOCK COMPRESSION BASE VALVE AND SWITCH THE BASE VALVE WITH THE NEW ONE.







- 3. TIGHT THE MAIN NUT AT 6 NM.
- 4. MOUNT THE COMPRESSION ADJUSTER ON THE FORK LUGS USING THE APPROPRIATE 21mm SOCKET WRENCH AT 32 NM AND APPLY GREASE ON THE THREAD TO AVOID ANY KIND OF ISSUE ON THE KIT.
- 5. BE SURE TO REMOVE THE NEEDLE INSIDE THE GREY AND RED REBOUND PISTON HOLDER AS SHOWED ON THE PICTURE BELOW INSIDE THE RED CIRCLE.





NOW YOU ARE READY TO MOUNT BACK THE COMPLETE FORK AS WELL.

WE HAVE SOME SUGGESTION TO REACH THE TOP FROM YOUR WP 4CS FORKS

- 1. USE SAE 7.5 ON THE FORKS ON MOTOCROSS USE.
- 2. USE SAE 5 ON ENDURO-OFF ROAD USE
- 3. TO REACH THE MAXIMUM RESULT ONLY USE OUR SINLUBIT OIL.
- 4. FOR A MEDIUM RIDER LEVEL USE 120 MM OF AIR CHAMBER. (ENDURO, OFF ROAD)
- 5. FOR A MEDIUM RIDER LEVEL USE 100 MM OF AIR CHAMBER (MOTOCROSS)

THIS IS A SETTING THAT WE SUGGEST ON THE COMPRESSION BASE VALVE DEPENDING ON THE RIDER'S WEIGHT (70/75~KG)

SHIMS ID 6			
5X28X025		5X28X025	
26X025		26X025	
24X020		24X020	
22X025		22X025	
20X020		20X020	
18X025		18X025	
16X020		16X020	
14X020		14X020	
12X020		12X020	_

OIL LEVEL MOTOCROSS 100
OIL LEVEL ENDURO-OFF-ROAD 120
SAE 7.5 MOTOCROSS
SAE 5 ENDURO-OFF-ROAD